im Vertrieb von CAMBOARD Electronics

Kramer Electronics, Ltd.

USER MANUAL

Model:

VS-44HDMI

4 x 4 HDMI Matrix Switcher

www.camboard.de Tel. 07131 911201ce-info@camboard.de
Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

Contents

1	**Introduction**	**1**
2	**Getting Started**	**1**
2.1	Quick Start	2
3	**Overview**	**3**
3.1	Defining the EDID	3
3.2	About HDMI	4
3.3	Terminology Used in this User Manual	5
4	**Your VS-44HDMI 4 x 4 HDMI Matrix Switcher**	**5**
5	**Installing the VS-44HDMI in a Rack**	**8**
6	**Connecting the VS-44HDMI 4 x 4 HDMI Matrix Switcher**	**9**
7	**Operating the VS-44HDMI 4 x 4 HDMI Matrix Switcher**	**10**
7.1	Routing Inputs to Outputs	10
7.2	Disconnecting the Outputs	10
7.3	Storing and Recalling a Setting	10
7.4	Acquiring the EDID	11
7.4.1	Acquiring an EDID from a Single Connected Output	11
7.4.2	Acquiring an EDID from Several Sets of Inputs and Outputs	12
7.4.3	Acquiring an EDID from Several Connected Outputs Automatically	13
7.4.4	Acquiring the Default EDID	13
7.5	Controlling via RS-232 (for example, using a PC)	14
7.6	Controlling via ETHERNET	14
7.6.1	Connecting the ETHERNET Port directly to a PC (Crossover Cable)	14
7.6.2	Connecting the ETHERNET Port via a Network Hub (Straight-Through Cable)	16
7.6.3	Control Configuration via the Ethernet Port	16
8	**Technical Specifications**	**17**
9	**Hex Table**	**17**
10	**Kramer Protocol 2000**	**18**

Figures

Figure 1: VS-44HDMI 4 x 4 HDMI Matrix Switcher Front and Rear Views 6
Figure 2: Connecting the VS-44HDMI 4 x 4 HDMI Matrix Switcher 9
Figure 3: Connecting a PC without using a Null-modem Adapter 14
Figure 4: Local Area Connection Properties Window 15
Figure 5: Internet Protocol (TCP/IP) Properties Window 16

www.camboard.de Tel. 07131 911201ce-info@camboard.de
Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

Tables

Table 1: Terminology Used in this User Manual 5
Table 2: VS-44HDMI 4 x 4 HDMI Matrix Switcher Front Panel Features 7
Table 3: VS-44HDMI 4 x 4 HDMI Matrix Switcher Rear Panel Features 7
Table 4: VS-44HDMI Technical Specifications 17
Table 5: VS-44HDMI Hex Codes for Switching via RS-232/RS-485 17
Table 6: Protocol Definitions 18
Table 7: Instruction Codes for Protocol 2000 19

www.camboard.de Tel. 07131 911201 ce-info@camboard.de
Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

1 Introduction

Welcome to Kramer Electronics! Since 1981, Kramer Electronics has been providing a world of unique, creative, and affordable solutions to the vast range of problems that confront the video, audio, and presentation professional on a daily basis. In recent years, we have redesigned and upgraded most of our line, making the best even better! Our 500-plus different models now appear in eight groups[1] that are clearly defined by function.

Thank you for purchasing the Kramer TOOLS **VS-44HDMI** *4 x 4 HDMI Matrix Switcher,* which is ideal for conference room presentations and advertising applications, as well as for rental and staging.

Each package includes the following items:

- The **VS-44HDMI** *4 x 4 HDMI Matrix Switcher*
- Power cord[2] and Null-modem adapter
- Windows®-based Kramer control software[3]
- Windows®-based Ethernet Configuration Manager and Virtual Serial Port Manager
- Kramer **RC-IR1/2** Infra-Red Remote Control Transmitter (including the required batteries and a separate user manual[4])
- This user manual[4]

2 Getting Started

We recommend that you:

- Unpack the equipment carefully and save the original box and packaging materials for possible future shipment
- Review the contents of this user manual
- Use Kramer high performance high resolution cables[5]

1 GROUP 1: Distribution Amplifiers; GROUP 2: Video and Audio Switchers, Matrix Switchers and Controllers; GROUP 3: Video, Audio, VGA/XGA Processors; GROUP 4: Interfaces and Sync Processors; GROUP 5: Twisted Pair Interfaces; GROUP 6: Accessories and Rack Adapters; GROUP 7: Scan Converters and Scalers; and GROUP 8: Cables and Connectors

2 We recommend that you use only the power cord supplied with this device

3 Downloadable from our Web site at http://www.kramerelectronics.com

4 Download up-to-date Kramer user manuals from our Web site at http://www.kramerelectronics.com

5 The complete list of Kramer cables is on our Web site at http://www.kramerelectronics.com

www.camboard.de Tel. 07131 911201ce-info@camboard.de
Fax 07131 911203

2.1 Quick Start

This quick start chart summarizes the basic setup and operation steps.

Step 1: Mount the machine - see section 5

Mount the machine in a rack or stick the 4 rubber feet to the underside



Step 2: Connect the inputs and outputs - see section 6

If required, connect a PC or a controller via RS-232 or the ETHERNET to control the VS-44HDMI

Connect the inputs and the outputs



Step 3: Turn the power ON

Step 4: Set the machine - see section 7

ROUTE AN INPUT TO AN OUTPUT

Press an output key followed by an input key to route this input to that output.

ACQUIRE THE EDID FROM:

- ❒ A connected output
- ❒ Several sets of inputs and outputs
- ❒ Several connected outputs
- ❒ The default EDID

STORE AND RECALL A SETUP

TO STORE:
1. Set the machine to the desired setting.
2. Press the STO button.
   The STO button blinks.
3. Select an IN or OUT button to store the machine setting.
4. Press the LOCK button to store the current setup.

TO RECALL:
1. Press the RCL button.
   The RCL button blinks.
2. Press the relevant OUT button.
3. Press the LOCK button to recall the stored setting.

Step 5: Operate the machine - see section 7

Operate via the front panel buttons, IR remote control, RS-232, and ETHERNET

www.camboard.de Tel. 07131 911201 ce-info@camboard.de
Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

3 Overview

The **VS-44HDMI** is a high-quality 4x4 matrix switcher for HDMI signals that features the following:

- Up to 1.65Gbps bandwidth per graphic channel[1]
- Four input selector buttons to switch to the four selectable outputs
- Support for HDCP (High Bandwidth Digital Content Protection)
- An OFF button to disconnect an output
- A PANEL LOCK button to prevent unwanted tampering with the buttons on the front panel
- 1U-high, 19" size for mounting in a professional rack enclosure

The **VS-44HDMI** can be controlled using the front panel buttons, or remotely via:

- RS-232 serial commands transmitted by a touch-screen system, PC, or other serial controller
- The Kramer infra-red remote control transmitter
- The ETHERNET

To achieve the best performance:

- Use only good quality connection cables[2] to avoid interference, deterioration in signal quality due to poor matching, and elevated noise levels (often associated with low quality cables).
- Avoid interference from neighboring electrical appliances that may adversely influence signal quality and position your Kramer **VS-44HDMI** away from moisture, excessive sunlight and dust

3.1 Defining the EDID

The EDID (Extended Display Identification Data[3]) is a data-structure, provided by a display, to describe its capabilities to an HDMI source. The EDID enables the **VS-44HDMI** to "know" what kind of monitor is connected to the output. The EDID includes the name of the manufacturer, the product type, the timing data supported by the display, the display size, luminance data and (for digital displays only) the pixel mapping data.

1 Suitable for resolutions up to UXGA at 60Hz, and for all HD resolutions

2 Available from Kramer Electronics on our Web site at http://www.kramerelectronics.com

3 Defined by a standard published by the Video Electronics Standards Association (VESA)

www.camboard.de Tel. 07131 911201ce-info@camboard.de
Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

3.2 About HDMI

HDMI (High-Definition Multimedia Interface) is an uncompressed all-digital[1] audio/video interface, widely supported in the entertainment and home cinema industry. It delivers the highest high-definition image and sound quality. Note that Kramer Electronics Limited is an HDMI Adopter[2] and an HDCP Licensee[3].

HDMI features:

- A simple[4] interface between any audio/video source, such as a set-top box, DVD player, or A/V receiver and video monitor, such as a digital flat LCD / plasma television (DTV), over a single long[5] cable
- A standard, enhanced, high-definition video, and multi-channel digital audio[6] on a single cable
- 8-channel digital audio, with spare bandwidth to accommodate future enhancements and compliance with all ATSC HDTV standards
- Superior, uncompressed digital video quality via a single cable[7], and user-friendly connector
- Backward-compatibility with DVI (Digital Visual Interface)
- Two-way communication between the video source (such as a DVD player) and the digital television, enabling new functionality such as automatic configuration and one-button play
- Support for existing high-definition video formats (720p, 1080i, and 1080p/60), standard definition formats such as NTSC or PAL, as well as 480p and 576p

1 Ensuring an all-digital rendering of video without the losses associated with analog interfaces and their unnecessary digital-to-analog conversions

2 See http://www.hdmi.org/about/adopters_founders.asp

3 See http://www.digital-cp.com/list/

4 With video and multi-channel audio combined into a single cable, the cost, complexity, and confusion of multiple cables currently used in A/V systems is reduced

5 HDMI technology has been designed to use standard copper cable construction at up to 15m

6 HDMI supports multiple audio formats, from standard stereo to multi-channel surround-sound. HDMI has the capacity to support Dolby 5.1 audio and high-resolution audio formats

7 HDMI provides the quality and functionality of a digital interface while also supporting uncompressed video formats in a simple, cost-effective manner

www.camboard.de Tel. 07131 911201 ce-info@camboard.de
Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

3.3 Terminology Used in this User Manual

Table 1 defines some terms that are used in this user manual.

Table 1: Terminology Used in this User Manual

Term	Definition
802.3	The standard specification for ETHERNET that is maintained by the Institute of Electrical and Electronics Engineers (IEEE).
Dynamic Host Configuration Protocol (DHCP)	Allows the network administrator to distribute IP addresses from a central point and automatically send a new IP address when an Ethernet point is plugged into a different network location.
Gateway	A network position serving as an entry to another network. On the Internet, a node or stopping point can be either a gateway node or a host (end-point) node.
IP Address	A 32-binary digit number that identifies each sender or receiver (within a network via a particular server or workstation) of data (HTML pages or e-mails) that is sent in packets across the Internet. Every device connected to an IP network must have a unique IP address. This address is used to reference the specific unit.
Local Area Network (LAN)	Computers sharing a common communications line or wireless link, which often share a server within a defined geographic area.
Media Access Control (MAC) Address	A computer's unique hardware number (or address) in a LAN or other network. On an Ethernet LAN, the (MAC) address is identical to the Ethernet address.
Transmission Control Protocol/Internet Protocol (TCP/IP)	The basic communication language or protocol of the Internet that breaks the message into appropriately sized packets for the network, and can be used as a communications protocol in an intranet or an extranet.

4 Your VS-44HDMI 4 x 4 HDMI Matrix Switcher

Figure 1, Table 2, and *Table 3* define the unit.

www.camboard.de Tel. 07131 911201ce-info@camboard.de
Fax 07131 911203



Figure 1: VS-44HDMI 4 x 4 HDMI Matrix Switcher Front and Rear Views

im Vertrieb von CAMBOARD Electronics

Table 2: VS-44HDMI 4 x 4 HDMI Matrix Switcher Front Panel Features

#	Feature	Function
1	IR Receiver LED	The red LED is illuminated when receiving signals from the Infra-red remote control transmitter
2	*POWER* Switch	Illuminated switch for turning the unit ON or OFF
3	*ALL* Button	Use ALL to select all inputs or all outputs (see section 7.1)
4	*OFF* Button	Use OFF to disconnect one or all outputs (see section 7.2)
5	*IN* Buttons	Press an INPUT selector button to select an input (from 1 to 4)
6	*OUT* Buttons	Press an OUTPUT selector button to select an output (from 1 to 4)
7	*STO* Button	Press to store an input setting
8	*RCL* Button	Press to recall an input setting
9	*LOCK* Button	Press to toggle disengaging the front panel buttons and to acquire the EDID (see section 7.4)
10	*EDID* Button[1]	Press to acquire the EDID
11	7-segment Display	Displays the selected input switched to the output (marked above each input)

Table 3: VS-44HDMI 4 x 4 HDMI Matrix Switcher Rear Panel Features

#	Feature	Function
12	*IN* HDMI Connectors	Connect to the HDMI sources (from 1 to 4)
13	*OUT* HDMI Connectors	Connect to the HDMI acceptors (from 1 to 4)
14	*RS-232* DB-9F Port	Connects to the PC or the RS-232 Remote Controller
15	*ETHERNET* Connector	Connects to the PC or other Ethernet Controller
16	*RESET* Button	Press the reset button to reset to the ETHERNET factory default definitions[2]: IP number – 192.168.1.39 Mask – 255.255.255.0 Gateway – 192.168.1.1
17	*REMOTE IR* Connector	Connect to an external IR receiver unit for controlling the machine via an IR remote controller (instead of using the front panel IR receiver)
18	Power Connector with Fuse	AC connector enabling power supply to the unit

1 Illuminates when configuring the EDID

2 First disconnect the power cord and then connect it again while pressing the RESET button. The unit will power up and load its memory with the factory default definitions

www.camboard.de Tel. 07131 911201ce-info@camboard.de
Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

5 Installing the VS-44HDMI in a Rack

This section describes how to install the **VS-44HDMI** in a rack.

Before Installing on a Rack

Before installing on a rack, be sure that the environment is within the recommended range:	
Operating temperature range	+5º to +45º C (41º to 113º F)
Operating humidity range	10 to 90% RHL, non-condensing
Storage temperature range	-20º to +70º C (-4º to 158º F)
Storage humidity range	5 to 95% RHL, non-condensing

CAUTION!!

When installing on a 19" rack, avoid hazards by taking care that:

1. It is located within the recommended environmental conditions, as the operating ambient temperature of a closed or multi unit rack assembly may exceed the room ambient temperature.
2. Once rack mounted, enough air will still flow around the machine.
3. The machine is placed straight in the correct horizontal position.
4. You do not overload the circuit(s). When connecting the machine to the supply circuit, overloading the circuits might have a detrimental effect on overcurrent protection and supply wiring. Refer to the appropriate nameplate ratings for information. For example, for fuse replacement, see the value printed on the product label.
5. The machine is earthed (grounded) in a reliable way and is connected only to an electricity socket with grounding. Pay particular attention to situations where electricity is supplied indirectly (when the power cord is not plugged directly into the socket in the wall), for example, when using an extension cable or a power strip, and that you use only the power cord that is supplied with the machine.

How to Rack Mount

To rack-mount a machine:

1. Attach both ear brackets to the machine. To do so, remove the screws from each side of the machine (3 on each side), and replace those screws through the ear brackets.



2. Place the ears of the machine against the rack rails, and insert the proper screws (not provided) through each of the four holes in the rack ears.

Note that:

- **In some models, the front panel may feature built-in rack ears**
- Detachable rack ears can be removed for desktop use
- Always mount the machine in the rack before you attach any cables or connect the machine to the power
- If you are using a Kramer rack adapter kit (for a machine that is not 19"), see the Rack Adapters user manual for installation instructions (you can download it at: http://www.kramerelectronics.com)

www.camboard.de Tel. 07131 911201 ce-info@camboard.de Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

6 Connecting the VS-44HDMI 4 x 4 HDMI Matrix Switcher

To connect the **VS-44HDMI**, as the example in *Figure 2* illustrates, do the following[1]:

1. Connect up to four HDMI sources[2] (for example, DVD players) to the IN HDMI connectors.
2. Connect the OUT HDMI connectors to up to four HDMI acceptors[3] (for example, LCD displays with built-in speakers).
3. If required, connect a PC and/or controller to the RS-232 port (see section 7.5) and/or the ETHERNET port (see section 7.6).
4. Connect the power cord (not shown in *Figure 2*).
5. If required, acquire the EDID (see section 7.1).



Figure 2: Connecting the VS-44HDMI 4 x 4 HDMI Matrix Switcher

1 Switch OFF the power on each device before connecting it to your **VS-44HDMI**. After connecting your **VS-44HDMI**, switch on its power and then switch on the power on each device

2 You do not have to connect all the HDMI sources

3 You do not have to connect all outputs

www.camboard.de Tel. 07131 911201ce-info@camboard.de
Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

7 Operating the VS-44HDMI 4 x 4 HDMI Matrix Switcher

This section describes how to:

- Route inputs to outputs (see section 7.1)
- Disconnecting outputs (see section 7.2)
- Store and recall a setup (see section 7.3)
- Acquire the EDID (see section 7.4)
- Control the machine via RS-232 (see section 7.5)
- Control the machine via the ETHERNET port (see section 7.6)

7.1 Routing Inputs to Outputs

To route an input to an output:

- Press an OUT key, followed by an IN key to route this input to that output

To route one input to all outputs:

- Press ALL followed by an IN button. The input is routed to all outputs

7.2 Disconnecting the Outputs

To disconnect one output:

- Press the OUT button of the output to disconnect and press OFF

To disconnect all outputs at once:

- Press the ALL button and then press OFF. This disconnects all the outputs

7.3 Storing and Recalling a Setting

You can use the STO and RCL buttons to store up to 8 setups and then recall them.

To store a setting:

1. Set the machine to the desired setting.
   For example, press the OUT 3 button and IN 4 button[1].
2. Press the STO button.
   The STO button blinks.

1 You can set all the switcher IN-OUT buttons

KRAMER: SIMPLE CREATIVE TECHNOLOGY
www.camboard.de Tel. 07131 911201 ce-info@camboard.de
Fax 07131 911203

3. Select an OUT or IN SELECT button to store the machine setting (for example, OUT 4).
4. Press the LOCK button[1] to store the current setup.
   In this example, the OUT 4 button stores the setting.

To recall a setup:

1. Press the RCL button.
   The RCL button blinks.
2. Press the relevant OUT or IN button that stored the setting.
   In this example, press OUT 4.
3. Press the LOCK button to recall the stored setting.

7.4 Acquiring the EDID

You can acquire the EDID from:

- A single connected output (see section 7.4.1)
- Several sets of inputs and outputs (see section 7.4.2)
- Several connected outputs automatically (see section 7.4.3)
- The default EDID (see section 7.4.4)

7.4.1 Acquiring an EDID from a Single Connected Output

To acquire or change the EDID of a new output display:

1. Power ON the **VS-44HDMI**.
2. Connect the required acceptor to the output from which you want to acquire the EDID.
3. Press the EDID and STO buttons simultaneously and hold them for 3 seconds.
   Both buttons flash.
4. Press the IN SELECTOR button to which the EDID will be copied.
   The selected input number flashes on the display.
5. Select the OUT SELECTOR button from which the EDID will be acquired.
6. Press the EDID button.
   The process is complete when the display returns to normal.

1 You have to press the LOCK button within 10 seconds, before the store operation times out

www.camboard.de Tel. 07131 911201ce-info@camboard.de
Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

7.4.2 Acquiring an EDID from Several Sets of Inputs and Outputs

To acquire the EDID several sets of inputs and outputs (for example, OUT 1 to IN 1 and OUT 6 to IN 3), do the following:

1. Power ON the **VS-44HDMI**.
2. Connect the required acceptors to the outputs from which you want to acquire the EDID.
3. Press the EDID and STO buttons simultaneously and hold them for 3 seconds.
   Both buttons flash.
4. Press the SELECT IN button to which the first EDID will be copied (for example, IN 1).
   The selected input number flashes on the display.
5. Press the SELECT OUT button from which the first EDID will be acquired (for example, OUT 1).
6. Press the SELECT IN 1 button again.
   The IN 1 button ceases to flash.
7. Press another SELECT IN to which the next EDID will be copied (for example, IN 3).
   The selected input number flashes on the display.
8. Press the SELECT OUT button from which the next EDID will be acquired (for example, OUT 4).
9. Press the SELECT IN 3 button again.
   The IN 3 button ceases to flash.
10. Press the SELECT IN buttons to which you want to copy the EDID (for example, IN 1 and IN 3).
11. Make sure that the relevant input numbers flash on the display.
12. Press the EDID button.
    The process is complete when the display returns to normal.

KRAMER: SIMPLE CREATIVE TECHNOLOGY
www.camboard.de Tel. 07131 911201 ce-info@camboard.de
Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

7.4.3 Acquiring an EDID from Several Connected Outputs Automatically

To automatically acquire or change the EDID of several output displays[1]:

1. Power ON the **VS-44HDMI**.
2. Connect the required acceptors to the outputs from which you want to acquire the EDID.
3. Press the EDID and STO buttons simultaneously and hold them for 3 seconds.
   Both buttons flash.
4. Press the SELECT IN button to which the EDID will be copied.
   The selected input number flashes on the display.
5. Press the OFF button until a "–" (hyphen) appears on the display.
6. Press the EDID button.
   The process is complete when the display returns to normal.

7.4.4 Acquiring the Default EDID

To reset to the default EDID, do the following:

1. Power ON the **VS-44HDMI**.
2. Press the EDID and STO buttons simultaneously and hold them for 3 seconds.
   Both buttons flash.
3. Press the SELECT IN button to which the EDID will be copied.
   The selected input number flashes on the display.
4. Press the OFF button until a "0" (zero) appears on the display.
5. Press the EDID button.
   The process is complete when the display returns to normal.

1 The EDID acquired is a weighted average of all the connected outputs. For example, if several displays with different resolutions are connected to the outputs, the acquired EDID supports all the resolutions, as well as other parameters included in the EDID

www.camboard.de Tel. 07131 911201ce-info@camboard.de
Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

7.5 Controlling via RS-232 (for example, using a PC)

To connect a PC to the **VS-44HDMI** unit, using the Null-modem adapter provided with the machine (recommended):

- Connect the RS-232 DB9 rear panel port on the **VS-44HDMI** unit to the Null-modem adapter and connect the Null-modem adapter with a 9-wire flat cable to the RS-232 DB9 port on your PC

To connect a PC to the **VS-44HDMI** unit, without using a Null-modem adapter:

- Connect the RS-232 DB9 port on your PC to the RS-232 DB9 rear panel port on the Master **VS-44HDMI** unit, as *Figure 3* illustrates


PIN 5 Connected to PIN 5 (Ground)
PIN 3 Connected to PIN 2
PIN 2 Connected to PIN 3
Female DB9 (From PC)
Male DB9
PIN 4 Connected to PIN 6
PINS 8, 7, 1 Connected together
If a Shielded cable is used, connect the shield to PIN 5

Figure 3: Connecting a PC without using a Null-modem Adapter

7.6 Controlling via ETHERNET

You can connect the **VS-44HDMI** via the Ethernet, using a crossover cable (see section 7.6.1) for direct connection to the PC or a straight-through cable (see section 7.6.2) for connection via a network hub or network router[1].

7.6.1 Connecting the ETHERNET Port directly to a PC (Crossover Cable)

You can connect the Ethernet port of the **VS-44HDMI** to the Ethernet port on your PC, via a crossover cable with RJ-45 connectors.

1 After connecting the Ethernet port, you have to install and configure your Ethernet Port. For detailed instructions, see the "Ethernet Configuration (FC-11) guide.pdf" file in the technical support section on our Web site: http://www.kramerelectronics.com

KRAMER: SIMPLE CREATIVE TECHNOLOGY
www.camboard.de Tel. 07131 911201 ce-info@camboard.de Fax 07131 911203

This type of connection is recommended for identification of the factory default IP Address of the **VS-44HDMI** during the initial configuration

After connecting the Ethernet port, configure your PC as follows:

1. Right-click the My Network Places icon on your desktop.
2. Select **Properties**.
3. Right-click Local Area Connection Properties.
4. Select **Properties**.
   The Local Area Connection Properties window appears.
5. Select the Internet Protocol (TCP/IP) and click the **Properties** Button (see *Figure 4*).



Figure 4: Local Area Connection Properties Window

6. Select Use the following IP Address, and fill in the details as shown in *Figure 5*.
7. Click **OK**.

www.camboard.de Tel. 07131 911201ce-info@camboard.de
Fax 07131 911203


Internet Protocol (TCP/IP) Properties
General
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.
Obtain an IP address automatically
Use the following IP address:
IP address:
192 . 168 . 1 . 2
Subnet mask:
255 . 255 . 255 . 0
Default gateway:
Obtain DNS server address automatically
Use the following DNS server addresses:
Preferred DNS server:
Alternate DNS server:
Advanced...
OK
Cancel

Figure 5: Internet Protocol (TCP/IP) Properties Window

7.6.2 Connecting the ETHERNET Port via a Network Hub (Straight-Through Cable)

You can connect the Ethernet port of the **VS-44HDMI** to the Ethernet port on a network hub or network router, via a straight-through cable with RJ-45 connectors.

7.6.3 Control Configuration via the Ethernet Port

To control several units via the Ethernet, connect the Master unit (Machine # 1) via the Ethernet port to the LAN port of your PC. Use your PC initially to configure the settings (see section 7.6).

www.camboard.de Tel. 07131 911201 ce-info@camboard.de
Fax 07131 911203
KRAMER: SIMPLE CREATIVE TECHNOLOGY

im Vertrieb von CAMBOARD Electronics

8 Technical Specifications

The **VS-44HDMI** technical specifications are shown in *Table 4*:

Table 4: VS-44HDMI Technical Specifications[1]

INPUTS:	4 HDMI Connectors
OUTPUTS:	4 HDMI Connectors
BANDWIDTH:	Supports up to 1.65Gbps bandwidth per graphic channel
COMPLIANCE WITH HDMI STANDARD:	Supports HDMI 1.1 and HDCP
MAX RESOLUTION:	Up to UXGA; 1080p, 1920 x 1200
POWER SOURCE:	100–240VAC; 50/60Hz, 28VA
CONTROLS:	Front panel buttons, Infra-red remote control transmitter, RS-232, Ethernet
DIMENSIONS:	19 " x 7 " x 1U W, D, H
WEIGHT:	2.5 kg. (5.5 lbs.) approx.
ACCESSORIES:	Power cord, IR transmitter
OPTIONS:	Kramer HDMI cables[2]

9 Hex Table

Table 5 lists the Hex values for a single machine (*MACHINE #* 1):

Table 5: VS-44HDMI Hex Codes for Switching via RS-232/RS-485

	OUT 1	OUT 2	OUT 3	OUT 4
IN 1	01	01	01	01
	81	81	81	81
	81	82	83	84
	81	81	81	81
IN 2	01	01	01	01
	82	82	82	82
	81	82	83	84
	81	81	81	81
IN 3	01	01	01	01
	83	83	83	83
	81	82	83	84
	81	81	81	81
IN 4	01	01	01	01
	84	84	84	84
	81	82	83	84
	81	81	81	81

1 Specifications are subject to change without notice

2 For best results, use Kramer cables such as the C-HDMI/HDMI series, the C-HDMI-DVI series and/or our HDMI over fiber optics C-FOHM/FOHM series

www.camboard.de Tel. 07131 911201ce-info@camboard.de
Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

10 Kramer Protocol 2000[1]

The **VS-44HDMI** is compatible with Kramer's Protocol 2000[2] (version 0.50) (below). This RS-232/RS-485 communication protocol uses four bytes of information as defined below. For RS-232, a null-modem connection between the machine and controller is used. The default data rate is 9600 baud, with no parity, 8 data bits and 1 stop bit.

Table 6: Protocol Definitions

MSB							LSB
	DESTINATION	**INSTRUCTION**					
0	D	N5	N4	N3	N2	N1	N0
7	6	5	4	3	2	1	0
1st byte							
	INPUT						
1	I6	I5	I4	I3	I2	I1	I0
7	6	5	4	3	2	1	0
2nd byte							
	OUTPUT						
1	O6	O5	O4	O3	O2	O1	O0
7	6	5	4	3	2	1	0
3rd byte							
			MACHINE NUMBER				
1	OVR	X	M4	M3	M2	M1	M0
7	6	5	4	3	2	1	0
4th byte							

1st BYTE: Bit 7 – Defined as 0.
D – "DESTINATION": 0 - for sending information to the switchers (from the PC);
1 - for sending to the PC (from the switcher).
N5…N0 – "INSTRUCTION"
The function that is to be performed by the switcher(s) is defined by the INSTRUCTION (6 bits). Similarly, if a function is performed via the machine's keyboard, then these bits are set with the INSTRUCTION NO., which was performed. The instruction codes are defined according to the table below (INSTRUCTION NO. is the value to be set for N5…N0).

2nd BYTE: Bit 7 – Defined as 1.
I6…I0 – "INPUT".
When switching (ie. instruction codes 1 and 2), the INPUT (7 bits) is set as the input number which is to be switched. Similarly, if switching is done via the machine's front-panel, then these bits are set with the INPUT NUMBER which was switched. For other operations, these bits are defined according to the table.

3rd BYTE: Bit 7 – Defined as 1.
O6…O0 – "OUTPUT".
When switching (ie. instruction codes 1 and 2), the OUTPUT (7 bits) is set as the output number which is to be switched. Similarly, if switching is done via the machine's front-panel, then these bits are set with the OUTPUT NUMBER which was switched. For other operations, these bits are defined according to the table.

4th BYTE: Bit 7 – Defined as 1.
Bit 5 – Don't care.
OVR – Machine number override.
M4…M0 – MACHINE NUMBER.

1 You can download our user-friendly "Software for Calculating Hex Codes for Protocol 2000" from the technical support section on our Web site at: http://www.kramerelectronics.com

2 The instruction codes in Table 7 are a sub-set of the Protocol 2000. You can find the full protocol on our Web site at http://www.kramerelectronics.com

www.camboard.de Tel. 07131 911201 ce-info@camboard.de Fax 07131 911203

Used to address machines in a system via their machine numbers. When several machines are controlled from a single serial port, they are usually configured together with each machine having an individual machine number. If the OVR bit is set, then all machine numbers will accept (implement) the command, and the addressed machine will reply.
For a single machine controlled via the serial port, always set M4…M0 = 1, and make sure that the machine itself is configured as MACHINE NUMBER = 1.

Table 7: Instruction Codes for Protocol 2000

Note: All values in the table are decimal, unless otherwise stated.

INSTRUCTION		DEFINITION FOR SPECIFIC INSTRUCTION		NOTE
#	DESCRIPTION	INPUT	OUTPUT	
0	RESET VIDEO	0	0	1
1	SWITCH VIDEO	Set equal to video input which is to be switched (0 = disconnect)	Set equal to video output which is to be switched (0 = to all the outputs)	2, 15
3	STORE VIDEO STATUS	Set as SETUP #	0 - to store 1 - to delete	2, 3, 15
4	RECALL VIDEO STATUS	Set as SETUP #	0	2, 3, 15
5	REQUEST STATUS OF A VIDEO OUTPUT	Set as SETUP #	Equal to output number whose status is reqd	4, 3
15	REQUEST WHETHER SETUP IS DEFINED / VALID INPUT IS DETECTED	SETUP # or Input #	0 - for checking if setup is defined 1 - for checking if input is valid	8
30	LOCK FRONT PANEL	0 - Panel unlocked 1 - Panel locked	0	2
31	REQUEST WHETHER PANEL IS LOCKED	0	0	16
61	IDENTIFY MACHINE	1 - video machine name 2 - audio machine name 3 - video software version 4 - audio software version 5 - RS422 controller name 6 - RS422 controller version 7 - remote control name 8 - remote software version 9 - Protocol 2000 revision	0 - Request first 4 digits 1 - Request first suffix 2 - Request second suffix 3 - Request third suffix 10 - Request first prefix 11 - Request second prefix 12 - Request third prefix	13
62	DEFINE MACHINE	1 - number of inputs 2 - number of outputs 3 - number of setups	1 - for video 2 - for audio 3 - for SDI 4 - for remote panel 5 - for RS-422 controller	14

NOTES on the above table:

NOTE 1 - When the master switcher is reset, (e.g. when it is turned on), the reset code is sent to the PC. If this code is sent to the switchers, it will reset according to the present power-down settings.

NOTE 2 - These are bi-directional definitions. That is, if the switcher receives the code, it will perform the instruction; and if the instruction is performed (due to a keystroke operation on the front panel), then these codes are sent. For example, if the HEX code
01 85 88 83
was sent from the PC, then the switcher (machine 3) will switch input 5 to output 8. If the user switched input 1 to output 7 via the front panel keypad, then the switcher will send HEX codes:
41 81 87 83
to the PC.
When the PC sends one of the commands in this group to the switcher, then, if the instruction is valid, the switcher replies by sending to the PC the same four bytes that it was sent (except for the first byte, where the DESTINATION bit is set high).

NOTE 3 - SETUP # 0 is the present setting. SETUP # 1 and higher are the settings saved in the switcher's memory, (i.e. those used for Store and Recall).

www.camboard.de Tel. 07131 911201ce-info@camboard.de
Fax 07131 911203

im Vertrieb von CAMBOARD Electronics

NOTE 4 - The reply to a "REQUEST" instruction is as follows: the same instruction and INPUT codes as were sent are returned, and the OUTPUT is assigned the value of the requested parameter. The replies to instructions 10 and 11 are as per the definitions in instructions 7 and 8 respectively. For example, if the present status of machine number 5 is breakaway setting, then the reply to the HEX code

0B 80 80 85
would be HEX codes
4B 80 81 85

NOTE 8 - The reply is as in TYPE 3 above, except that here the OUTPUT is assigned with the value 0 if the setup is not defined / no valid input is detected; or 1 if it is defined / valid input is detected.

NOTE 13 - This is a request to identify the switcher/s in the system. If the OUTPUT is set as 0, and the INPUT is set as 1, 2, 5 or 7, the machine will send its name. The reply is the decimal value of the INPUT and OUTPUT. For example, for a 2216, the reply to the request to send the audio machine name would be (HEX codes):
7D 96 90 81 (i.e. 128dec+ 22dec for 2nd byte, and 128dec+ 16dec for 3rd byte).

If the request for identification is sent with the INPUT set as 3 or 4, the appropriate machine will send its software version number. Again, the reply would be the decimal value of the INPUT and OUTPUT - the INPUT representing the number in front of the decimal point, and the OUTPUT representing the number after it. For example, for version 3.5, the reply to the request to send the version number would be (HEX codes):
7D 83 85 81 (i.e. 128dec+ 3dec for 2nd byte, 128dec+ 5dec for 3rd byte).

If the OUTPUT is set as 1, then the ASCII coding of the lettering following the machine's name is sent. For example, for the VS-7588YC, the reply to the request to send the first suffix would be (HEX codes):
7D D9 C3 81 (i.e. 128dec+ ASCII for "Y"; 128dec+ ASCII for "C").

NOTE 14 - The number of inputs and outputs refers to the specific machine which is being addressed, not to the system. For example, if six 16X16 matrices are configured to make a 48X32 system (48 inputs, 32 outputs), the reply to the HEX code
3E 82 81 82 (ie. request the number of outputs)
would be HEX codes
7E 82 90 82
ie. 16 outputs

NOTE 15 – When the OVR bit (4th byte) is set, then the "video" commands have universal meaning. For example, instruction 1 (SWITCH VIDEO) will cause all units (including audio, data, etc.) to switch. Similarly, if a machine is in "FOLLOW" mode, it will perform any "video" instruction.

NOTE 16 - The reply to the "REQUEST WHETHER PANEL IS LOCKED" is as in NOTE 4 above, except that here the OUTPUT is assigned with the value 0 if the panel is unlocked, or 1 if it is locked.

www.camboard.de Tel. 07131 911201 ce-info@camboard.de
Fax 07131 911203

LIMITED WARRANTY

Kramer Electronics (hereafter *Kramer*) warrants this product free from defects in material and workmanship under the following terms.

HOW LONG IS THE WARRANTY

Labor and parts are warranted for seven years from the date of the first customer purchase.

WHO IS PROTECTED?

Only the first purchase customer may enforce this warranty.

WHAT IS COVERED AND WHAT IS NOT COVERED

Except as below, this warranty covers all defects in material or workmanship in this product. The following are not covered by the warranty:

1. Any product which is not distributed by Kramer, or which is not purchased from an authorized Kramer dealer. If you are uncertain as to whether a dealer is authorized, please contact Kramer at one of the agents listed in the Web site www.kramerelectronics.com.
2. Any product, on which the serial number has been defaced, modified or removed, or on which the WARRANTY VOID IF TAMPERED sticker has been torn, reattached, removed or otherwise interfered with.
3. Damage, deterioration or malfunction resulting from:
   i) Accident, misuse, abuse, neglect, fire, water, lightning or other acts of nature
   ii) Product modification, or failure to follow instructions supplied with the product
   iii) Repair or attempted repair by anyone not authorized by Kramer
   iv) Any shipment of the product (claims must be presented to the carrier)
   v) Removal or installation of the product
   vi) Any other cause, which does not relate to a product defect
   vii) Cartons, equipment enclosures, cables or accessories used in conjunction with the product

WHAT WE WILL PAY FOR AND WHAT WE WILL NOT PAY FOR

We will pay labor and material expenses for covered items. We will not pay for the following:

1. Removal or installations charges.
2. Costs of initial technical adjustments (set-up), including adjustment of user controls or programming. These costs are the responsibility of the Kramer dealer from whom the product was purchased.
3. Shipping charges.

HOW YOU CAN GET WARRANTY SERVICE

1. To obtain service on you product, you must take or ship it prepaid to any authorized Kramer service center.
2. Whenever warranty service is required, the original dated invoice (or a copy) must be presented as proof of warranty coverage, and should be included in any shipment of the product. Please also include in any mailing a contact name, company, address, and a description of the problem(s).
3. For the name of the nearest Kramer authorized service center, consult your authorized dealer.

LIMITATION OF IMPLIED WARRANTIES

All implied warranties, including warranties of merchantability and fitness for a particular purpose, are limited in duration to the length of this warranty.

EXCLUSION OF DAMAGES

The liability of Kramer for any effective products is limited to the repair or replacement of the product at our option. Kramer shall not be liable for:

1. Damage to other property caused by defects in this product, damages based upon inconvenience, loss of use of the product, loss of time, commercial loss; or:
2. Any other damages, whether incidental, consequential or otherwise. Some countries may not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from place to place.

NOTE: All products returned to Kramer for service must have prior approval. This may be obtained from your dealer.

This equipment has been tested to determine compliance with the requirements of:

EN-50081:	"Electromagnetic compatibility (EMC); generic emission standard. Part 1: Residential, commercial and light industry"
EN-50082:	"Electromagnetic compatibility (EMC) generic immunity standard. Part 1: Residential, commercial and light industry environment".
CFR-47:	FCC Rules and Regulations: Part 15: “Radio frequency devices Subpart B Unintentional radiators”

CAUTION!

- Servicing the machines can only be done by an authorized Kramer technician. Any user who makes changes or modifications to the unit without the expressed approval of the manufacturer will void user authority to operate the equipment.
- Use the supplied DC power supply to feed power to the machine.
- Please use recommended interconnection cables to connect the machine to other components.

For the latest information on our products and a list of Kramer distributors, visit our Web site: www.kramerelectronics.com where updates to this user manual may be found.
We welcome your questions, comments and feedback.

Safety Warning:
Disconnect the unit from the power supply before opening/servicing.

Kramer Electronics, Ltd.
Web site: www.kramerelectronics.com
E-mail: info@kramerel.com
P/N: 2900-000359 REV 1

www.camboard.de Tel. 07131 911201ce-info@camboard.de
Fax 07131 911203